



The elegant way of expressing your own style.



Please make sure that the integrated ekey dLine finger scan is only compatible with and may only be connected to the ekey dLine controller. Please make sure that the FS-Arte ekey is only connected to the Integra Plus or Micro Plus control units.

GB CARE INFORMATION FOR THE FINGER SCANNER

The system is basically maintenance-free.

However, should the finger scanner become soiled, it can be cleaned using a moist (not wet), non-abrasive cloth. Cotton buds, microfibre and lens cleaning cloths for glasses are all suitable.



Don't use cotton cloths, paper towels and tissues, kitchen sponges, moist tea towels and kitchen roll paper.

Be very gentle when cleaning the sensor surface.

Use only water for moistening, never add cleaning agents.

Be very careful when cleaning the stainless steel handle with stainless steel polish or cleaner, as the finger scanner should not come into contact with the cleaning agent.

We hope you enjoy your finger scanner.